
CENTER: LONG PILOT Centers BOTH

Bearing and Spacer.



Plan for

**CLEARANCE** 

CENTER:

SHORT PILOT

0-RINGS